

# Flexam EF 12/2 0+A54 black AS FR

Article code: SBFL589500

## General information

<b>Product group</b>	Synthetic Belts
<b>Industry segment</b>	Airports; Logistics: Distribution & warehousing
<b>Main product feature</b>	Antistatic, Flame retardant
<b>Indication of use</b>	Slider bed, Rollers, Flat, Troughed

## Belt construction

<b>Tension layer</b>		polyester, flexible
<b>Number of plies</b>		2
<b>Top side</b>	<b>material</b>	Flexam, PVC
	<b>finish</b>	profile, A54 Marathon profile
	<b>color</b>	black
<b>Bottom side</b>	<b>material</b>	polyester
	<b>finish</b>	bare fabric
	<b>color</b>	natural

## Characteristics

<b>Food Grade (FG)</b>	no	
<b>Antistatic (AS)</b>	yes	ISO 21178
<b>High conductive (HC)</b>	no	
<b>Flame-retardant</b>	yes	ISO 340
	no	
<b>ATEX approval</b>	no	

## Technical data

<b>Hardness</b>	ISO 868	top side	70A Shore	
<b>Force at 1% elongation (static)</b>	ISO 21181		12 N/mm	68.52 lbs/in.
<b>Thickness</b>	AB method KV.002	total	2.50 mm	0.1 in.
		top cover	0.90 mm	0.04 in.
<b>Weight</b>	AB method KV.004		2.6 kg/m <sup>2</sup>	0.53 lbs/ft <sup>2</sup>
<b>Coefficient of friction</b>	bottom against steel	dynamic	0.19	
		static	0.22	
	top against steel	dynamic	> 1.0	
		static	> 1.5	
<b>Operating temperature</b>	continuous	from / to	-15 / 80 °C	5 / 176 °F
	short	from / to	-30 / 100 °C	-22 / 212 °F
<b>Minimum pulley diameter</b>	flexing		50 mm	1.97 in.
	backflexing		80 mm	3.15 in.
<b>Manufacturing width</b>	standard		3000 mm	118.11 in.
	maximum		3200 mm	125.98 in.

## Fabrication

Hot splicing is always preferable. Glueing can only be done when the belt is exposed to normal temperature and the humidity is not excessive.

For the working method, consult the splice information and the equipment literature. Apply the recommended splice as indicated in the separate information.

### Additional information

This sheet contains typical values, which apply to a temperature of approx. 20 °C (68 °F), unless otherwise stated, individual data may differ.

We recommend to keep the belt tension to a practical working minimum to maximize the service life of the belt and machine parts.

Always protect belts from sunlight/UV-radiation, avoid temperatures below 10°C and above 40°C, dust and dirt. Store belts in a cool and dry place and if possible in their original packaging.

For details consult 'Storage and handling instructions' or contact our specialist.