Technical datasheet

Flexam EX 10/2 0+A32 black AS

Ammeraal Beltech

Article code: SBFL574122

General information							
Product group	Synthetic Belts						
Industry segment	Airports; Logistics: Distribution & warehousing; Building materials: Insulation						
Main product feature Antistatic, Low noise							
Indication of use							
Belt construction							
Tension layer			polyester, stable				
Number of plies			2				
Top side	material		Flexam, PVC				
	finish	profile, A32 Fine rib profile					
	color		black				
Bottom side	material		fabric, polyester				
	finish		bare fabric				
	color		natural				
Characteristics							
Food Grade (FG)	no						
Antistatic (AS)	static (AS) yes		ISO 21178				
High conductive (HC)	no						
Flame-retardant	no						
	yes		ASTM D-378				
ATEX approval	no						
Technical data							
Hardness			o side		Shore		
Force at 1% elongation (static)	ISO 21181				N/mm		lbs/in.
Elastic modulus (k1% relaxed)	ISO 21181				N/mm		lbs/in.
Thickness	AB method KV.002 to			2.60		0.1	
		top	o cover	1.00		0.04	
Weight	AB method KV.004				kg/m²	0.45	lbs/ft²
Coefficient of friction	bottom against steel		namic	0.15			
			itic	0.17			
	top against steel		namic	> 1.0			
.			itic	> 1.5		10 (176	05
Operating temperature	continuous	from / to		-25 / 80		-13 / 176	
Minimum multiple diameters	short	fro	m / to	-25 / 100		-13 / 212	
Minimum pulley diameter	flexing				mm	0.98	
	backflexing				mm	1.57	
Manufacturing width	standard			2020		79.53	
	maximum			3000	mm	118.11	ın.

Fabrication

Hot splicing is always preferable. Glueing can only be done when the belt is exposed to normal temperature and the humidity is not excessive. For the working method, consult the splice information and the equipment literature. Apply the recommended splice as indicated in the seperate information.

Additional information

This sheet contains typical values, which apply to a temperature of approx. 20 °C (68 °F), unless otherwise stated, individual data may differ.

We recommend to keep the belt tension to a practical working minimum to maximize the service life of the belt and machine parts.

Always protect belts from sunlight/UV-radiation, avoid temperatures below 10°C and above 40°C, dust and dirt. Store belts in a cool and dry place and if possible in their original packaging.

For details consult 'Storage and handling instructions' or contact our specialist.

Because of continuous development, the presented data is subject to alteration. This data replaces that included in previous publications. Ammeraal Beltech excludes any liability for the incorrect use of the above stated information. Subject to the general terms and conditions of sale and delivery, as applied by its operating companies, are all activities performed and services rendered by Ammeraal Beltech.